



Asus Vivobook S500CA RAM Replacement

How to replace an Asus Vivobook S500CA's RAM.

Written By: Sydney Price



INTRODUCTION

If your computer is running slower than you would like, use this guide to replace your RAM. This model will support up to 8GB of RAM.



TOOLS:


- [Philips Head Screwdriver: Size PH1](#) (1)
-

Step 1 — RAM




- Turn the device over so the back plate is facing up.

Step 2




- Use a Philips Head PH1 screwdriver to remove 10 screws around the perimeter of the back plate.
- ⓘ Place screws where they cannot be lost as they will be used to replace the back plate.

Step 3





- Remove the back plate by lifting it straight up.

Step 4



- Push away the tabs on the left and right sides of the RAM cartridge to release the cartridge.
- ⓘ Another pair of hands will make the process easier.

Step 5



- Slide the cartridge directly away from its housing.

This document was last generated on 2017-06-17 08:04:43 AM.